




Aileron installation

step 01



Aileron installation


step 02







Aileron installation


step 05



Aileron installation


step 06






Aileron installation

step 09



Aileron installation


step 10






Aileron installation

step 13




Aileron installation

step 14










Rudder installation

step 21



Rudder installation

step 22





Rudder installation


step 23



Rudder installation

step 24






Rudder installation



step 27




Rudder installation

step 28



Rudder installation

step 29




Rudder installation

step 30




Rudder installation

step 31




Rudder installation

step 32



step 34



Elevator installation

step 35




Elevator installation

step 36




5 min



Elevator installation

step 37



Elevator installation

step 38



Elevator installation

step 39




5 min




Elevator installation

step 40




Elevator installation

step 42



Elevator installation

step 43



Elevator installation

step 43



Rudder servo installation

step 44




Rudder servo installation


step 45




Rudder servo installation

step 46











Stabilizer installation

step 55



Elevator servo installation

step 56



Elevator servo installation


step 57




Elevator servo installation

step 58









Landing Gear installation

step 63



Landing Gear installation

step 64





Landing Gear installation

step 67



Landing Gear installation

step 68




Landing Gear installation

step 69




Landing Gear installation

step 70



Electric motor version

step 71



Electric motor version

step 72




Electric motor version

step 73



Electric motor version

step 74



Electric motor version

step 75




Electric motor version

step 76




Electric motor version

step 77




Electric motor version

step 78



Electric motor version



step 79




Electric motor version

step 80









Wing panel installation

step 85



Wing panel installation

step 86





step 89



step 90



Decals

step 91



Decals

step 92

